


## Profile's selection



### Turning on the Bluetooth® radio

To enable the Bluetooth® technology on the Sylvac instrument :


- Press the Mode button until reaching the menu « *bt* ». (1)
- Then enter the menu by pressing the Set button, press it one more time to reach « *On* ». (2)
- Validate by pressing the Data button. (3)
- The Bluetooth® radio is turned on (4)



### Selecting the Bluetooth® profiles (SIMPLE, PAIRED, HID)

To select the Bluetooth® profiles needed :

- Press the Mode button (>2s) to reach the advanced menu list (1), then press Mode until reaching the menu « *bt CFG* ». (2)
- Then enter the menu by pressing the Set button (2), press it again to reach the wanted profile « *SIMPLE* », « *PAIR* » or « *Hid* ». (The symbol «\*» informs you about the current selected profile) (3)
- Validate by pressing the Data button. (3)
- Your profile is now activated. (4)





# Instrument & Bluetooth® reset



## Reset of all the instrument settings using the Mode and Set buttons

To reset the instrument and remove all pairing from devices (the selected profile doesn't change and the Bluetooth® technology is turned on. The instrument parameters go back to factory settings) :

- Press simultaneously the Mode and Set buttons (>4s) until you see « *rESEt* » on the display (1), then release the pression. (2)
- The instrument reboots. (3)
- The instrument and the Bluetooth® connection are now reset. (4)



## Reset of the Bluetooth® pairing information

To reset the Bluetooth® and remove all pairing from device :

- Press the Mode button until reaching the menu « *bt* ». (1)
- Then enter the menu by pressing the Set button (2), press it again to reach the « *rESEt* » menu. (3)
- Validate by pressing the Data button. (3)
- The Bluetooth® connection is now reset. (4)

\*Only valid for *PAir* and *HiD* profiles.